

Master Flash® Retrofit Square Vent



Select an appropriate Master Flash® Retrofit with a pipe range that goes below and beyond fitting. If necessary, follow the lines clearly shown on the flashing and create an opening 10-20% smaller than pipe diameter. Slice down the flange. For the steep roof slopes or higher corrugation of the profile, bigger size of Master Flash® should be chosen.



Wrap Master Flash® Square Vent around the pipe and install all snap rivets to seal the flange.



Press Master Flash® down, bending it to conform to roof profile or irregularities. A blunt tool will help to form flashing to tight roof angles.



Use fasteners to complete sealing. For installation, fastener spacing must not exceed 38 mm (1.5").



Make a hole in the flange to insert a cable tie or steel band depending on product material. Slide the cable tie through the hole, ensuring that it is resting on the flashing. Put the cable through the hole to assure tight fitting. Additional sealant may be applied between the flashing and the pipe. Apply as needed.